



Play-Fi Device (

Unison


MartinLogan

7CB77B02932D




Mon September 12 2022

Front Left



● Target Curve ● Measurement Curve ● Corrected Curve

Front Right



● Target Curve ● Measurement Curve ● Corrected Curve

Speaker Profile Settings

Profile1 uses Measurement A

List of Speakers Enabled

Profile1:

· Fronts

Level Settings

Profile1:

System-Wide Level Target: 0 dB

Front Left: 0 dB

Front Right: 0 dB

Target Settings

Profile1:

Room Gain: 4 dB

Room Gain Center Frequency: 200 Hz

Deep Bass Boost: 1 dB

Deep Bass Boost Center Frequency: 50 Hz

Tilt Level: 0 dB

Tilt Start Frequency: 100 Hz

FRONTS

Subwoofer Crossover Frequency (or Low-Frequency Extension): 25 Hz

Send Bass to Sub (or Low-Frequency Extension Slope): 4th

High-Frequency Roll Off: 1.72

Maximum Correction Frequency: 1400 Hz