

Shanling M0 Firmware 2.5

New functions guide

1. Lock screen

To enable: Go to “System” settings, to “Lock screen”. In this submenu, Lock screen can be enabled or disabled and custom lock screen wallpaper can be chosen.

Lock screen: Volume setting can be accessed on Lock screen.
Swipe right to unlock device.

Custom lock screen wallpaper:

1. Images must be stored in “lockscreenimage” folder, located in root folder of Micro SD card.
2. Supports PNG and JPG, resolution exactly 240 x 240, under 1MB.
3. Maximum of 5 images in folder.

2. Additional connectivity of Bluetooth and USB

Bluetooth USB transport

Allowing any smartphone or computer to stream audio into standalone DAC, via Shanling player, over Bluetooth connection.

- 1) Connect Shanling player to standalone DAC over appropriate cable.
- 2) Connect your smartphone or computer to Shanling player over Bluetooth, switching Shanling player into Bluetooth receiver mode.

Now all sounds from your smartphone or computer will be streamed into Shanling player, which will send audio into connected standalone DAC over USB cable.

USB Bluetooth transmitter

Allowing any computer to stream music over Bluetooth in high quality, using USB cable connection.

- 1) Connect Bluetooth headphones or speakers to Shanling player.
- 2) Set Shanling player into USB DAC mode – “System” setting, “USB Mode” set to DAC.
- 3) Connect Shanling player to computer over USB cable (Drivers must be installed on Windows system) and set it as default audio device.

Now all sounds from your computer will be streamed to your connected Bluetooth Headphones or speakers. Bluetooth quality will be displayed in status bar of Shanling player.

Bluetooth USB Transport



USB Bluetooth transmitter

